



PRO-TUNER EFI DISTRIBUTOR WITH CAM-SYNC For Small-Block and Big-Block Chevrolet V8 Catalog #3615

INSTALLATION INSTRUCTIONS

PLEASE study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday or e-mail us at Edelbrock@Edelbrock.com.

IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation will void your warranty and may result in poor performance and engine or vehicle damage.

DESCRIPTION: The Pro-Tuner Distributor with Cam-Sync is designed for use with our Victor and Super Victor Pro-Tuner EFI systems for the Small Block and the Big Block Chevrolet. It is also compatible with other aftermarket EFI management systems. The distributor includes an adjustable hold down collar (to accommodate various deck heights and custom intake manifolds), a large Ford-style distributor cap, and the mechanical advance is locked out. It is equipped with a steel distributor drive gear. The Pro-Tuner distributor also features a Magnetic Crank Pickup and uses a Hall-Effect Cam-Sync Pickup with LED indicator for the Camshaft Sensor. The Cam-Sync pickup can be adjusted manually or with EFI management software to achieve the proper lead time required by your ECU. The Cam Sync has a 12" lead and a 3-prong Weatherpak connector. The crank trigger has an 8" lead and 2-prong Weatherpak connector.

KIT CONTENTS:

- | | |
|--|---|
| <input type="checkbox"/> 1 Pro-Tuner Distributor | <input type="checkbox"/> 2 1.5" Long, Self Tapping Screws |
| <input type="checkbox"/> 1 Rotor (MSD #8421) | <input type="checkbox"/> 1 Distributor Gasket |
| <input type="checkbox"/> 1 Distributor Cap (MSD #8408) | <input type="checkbox"/> 2 O-Rings |
| <input type="checkbox"/> 1 Wire Retainer | <input type="checkbox"/> 1 Tube of Assembly Lube |


BEFORE BEGINNING INSTALLATION

- **WARNING:** When installing the distributor, make sure to disconnect the vehicle's battery **BEFORE** beginning the installation.
- **NOTE:** If the drive gear is ever replaced, you must use a MSD #8531 distributor drive gear due to the .500" diameter drive shaft.
- **HALL-EFFECT PICKUP**

LED OPERATION: The LED is on whenever the magnet is NOT in front of the pickup. The LED Turns off when the magnet passes over the center of the pickup (approximately 40°) (**See Figure 1**).

Specifications

Accepts 5-18 Volts continuous
Output: Within 1.5 volts on the red wire, and .3 volts above ground
Protected from reverse polarity, short circuit and over voltage



WIRE FUNCTIONS




Figure 1 - Hall Effect Sensor

O-RING SEALS

The Pro-Tuner Distributor features an o-ring groove in the uppermost bottom land of the housing in order to seal the oil gallery. The o-ring should only be installed if the block has been modified (**See Figure 2**).




Figure 2 - Block Modification O-Ring (Dual O-Ring Type Shown)

ADJUSTABLE SLIP COLLAR

The Pro-Tuner Distributor features an adjustable slip collar. This allows the distributor to accommodate variations in block height, modified intake manifolds or cylinder heads. It is recommended to check the slip collar setting before installation:

1. Loosen the slip collar and insert the distributor into the engine until it bottoms out on the oil pump drive.
2. Raise the distributor .010" to .030" from bottomed out, then slide the slip collar down into position and tighten the collar.

CHECKING THE DISTRIBUTOR DRIVE GEAR MESH

It is recommended to check for proper gear mesh between the drive gear on the camshaft and the drive gear on the distributor. In order to check the mesh, coat the distributor gear with the supplied assembly lube and install the distributor into the engine. Rotate the engine several

revolutions and remove the distributor. The mesh pattern in the lube should be even and in the middle of the gear. Adjust the slip collar to obtain the proper mesh, if necessary.

CHECKING THE OIL PUMP TO DISTRIBUTOR SHAFT OVERLAP

After checking the drive gear mesh, it is very important to have the proper overlap between the distributor shaft and the oil pump shaft. The tongue of the distributor shaft should sit into the oil pump shaft groove by a minimum of 1/4". Check this measurement according to the procedure below:

1. Measure the distance between the base of the slip collar and the tip of the distributor shaft (**See Figure 3**).




Figure 3 - Oil Pump Shaft to Distributor Shaft Overlap

2. Using a straight edge, measure the distance from the intake manifold distributor flange to the top of the oil pump intermediate shaft (**See Figure 3**).
3. Subtract the measurement from Step 1 from the measurement taken in Step 2. This difference is the overlap. If there is too much, or not enough clearance, a shorter or longer oil pump drive shaft will be required.

INSTALLATION PROCEDURE

NOTE: If installing distributor with Edelbrock Pro-Tuner EFI kit #3670 or 3690, see your User's Guide for detailed installation instructions.

1. Rotate the crankshaft until cylinder #1 is coming up on the compression stroke. Stop turning when the crankshaft is at the desired initial timing (i.e. 10° BTDC).
2. Liberally apply assembly lube to the distributor gear. Install the distributor (using the supplied gasket) so that the rotor comes to rest pointing at what will be the #1 terminal on the cap (**See Figure 4**). Position the cap such that #1 is in the same location as it was on your previous distributor. Remove and reinsert the distributor to align the distributor, if necessary. Make sure the distributor seats down completely and has fully engaged the oil pump drive. You may need to rotate the oil pump shaft.
3. Lift the rotor by hand to make sure that there is adequate endplay. Lack of endplay indicates that the rotor shaft is bottomed out on the oil pump shaft.




Figure 4 - Marking Rotor Position

- Lightly tighten the hold down clamp so that the distributor can still be turned to determine final setting when checking the timing.
- Re-attach the distributor cap. Make sure the rotor is still pointing to #1.
- Install your spark plug and coil wires and connect the distributor to the wiring harness. Make sure to install the spark plug wires one at a time and verify they are in the correct position. A wire retainer is supplied to secure the wires to the cap. Align the retainer with the mounting bosses, and use the supplied 1.5" self-tapping screws to secure the retainer.

NOTE: DO NOT use a Solid-Core type spark plug wire set, such as copper core, etc. You must use a suppression type spark plug wire. Failure to use the correct wires will cause electrical interference with the engine control unit.

SETTING THE CAM SYNC PICKUP

The Hall-Effect pickup is designed to provide an aftermarket ECU with a sync signal. This signal must be advanced more than the ignition trigger signal. The amount of advance or lead time depends upon the ECU being used. Always check with the ECU manufacturer for the amount of lead time required for the cam sync.

NOTE: Adjustment to the cam sync pickup is not necessary when using the distributor with Edelbrock Pro-Tuner EFI kit 3670 or 3690. For all other installations, refer to **Figure 5 and 6** for examples of the display of the crank and cam sync sensor outputs.

- After the distributor is locked in place at the desired total timing, rotate the engine until the #1 cylinder is at the required cam sync. For example: If 10° of sync is required, and the total timing is at 36° BTDC, rotate the engine until the #1 cylinder is at 46° BTDC.
- With power going to the Hall-Effect pickup, adjust the pickup until the light turns off (The voltage output will be higher. Refer to the Hall-Effect sensor information on page 1 for reference). This will be the advance for the ECU. It is important to rotate the pickup clockwise until the light turns on, and then rotate the pickup counter-clockwise until the light just turns off.
- Lock the pickup sync in position.




Figure 5 - View of Distributor Output Signal




Figure 6 - View of Distributor Output Signal

ROTOR PHASING

Rotor phasing is defined as the alignment between the rotor tip and the distributor cap terminal when the spark occurs (**See Figure 7**). This position can be very important to your engine's performance. If the alignment is incorrect, the spark will jump to the next closest terminal, or another ground resulting in a misfire and loss of power. In applications with extreme cylinder pressures, such as with nitrous or forced induction, correct rotor phasing increases in importance. More voltage is required to ionize the plug gap and if rotor phasing is off, the spark is more apt to find an easier path to ground rather than the correct cap terminal. This may result in severe engine damage.




Figure 7 - Rotor Phasing

In order to check rotor phasing, you will need to modify a distributor cap so you can observe the rotor tip with a timing light when the engine is running. Drill a large hole into a cap near a terminal that will allow you an easy view of the terminal (**See Figure 8**). To help see the rotor tip, mark it with white correction fluid. With the modified cap installed, connect the timing light to the corresponding plug wire. Start the engine and run at a steady speed. Shine the timing light into the cap and make note of the relation of the rotor tip to the terminal when spark occurs.

Since the timing is going to be controlled electronically, it is important to position the rotor phasing at, or near the total timing (most advanced).




Figure 8 - Modified Distributor Caps

Crank Trigger Applications: In crank trigger applications, the distributor does not control the ignition timing so adjusting rotor phasing is easy. Simply rotate the distributor housing until the rotor tip is in the correct position.

Phasing and Electronic Timing Controls: When setting the phasing, you also need to take into consideration any timing controls or retard controls. If you are advancing or retarding the timing electronically, you are affecting rotor phasing. In most cases, the timing change will not be enough to affect the phasing, but there are certain applications to watch out for. One such application is engines using multiple stage nitrous systems and retard steps. High performance, nitrous engines undergo extreme increases in cylinder pressures, which is why timing is generally taken out with each stage of nitrous. If your application pulls out a total of 16°, it is important to take this into consideration when setting the phasing. If you remove 16° of timing, the rotor tip will be past the cap terminal when it fires. On engines with extreme cylinder pressures and high rpm, this could easily cause a misfire or spark scatter which could result in severe engine damage. It is recommended to divide the total amount of retard and set the phasing at that point. For example, if the timing retard control takes out 16° of timing, you should set the rotor phasing when the timing is 8° retarded. This way, with no retards activated the phasing will be 8° advanced, or just in front of the distributor cap terminal and when the full amount of retard is activated, the phasing will be just after the terminal (on clockwise rotating distributors) (See Figure 9). Whenever checking the rotor phasing with an electronic timing control, it is important to check it with the retard activated and not activated.

NOTE: Re-check the Cam Sync position after setting the rotor phasing.

CARE AND MAINTENANCE

Periodically, visually inspect the cap terminals and rotor tip for wear and look for traces of carbon tracking where spark scatter occurs. Check your spark plug wires for burns or tears. It is also recommended to periodically test the resistance of the wires. See Figure 10 for an exploded view of the distributor and its parts.




Figure 9 - Rotor Phasing with Timing Control




Figure 10 - Pro-Tuner Distributor

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503
Tech-Line: 1-800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**