





757-842-6497
WWW.JLOSC.COM


**J&L 3.0 Oil Separator (2009-2018 Ram 1500 5.7 Hemi; 2019-2021 Ram 1500 "Classic" Passenger Side)
#3065P**

Installation Instructions

Check out the install video on our website www.JLosc.com Search: 3065P and click videos

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) J&L Oil Separator w/fittings, (1) J&L Mounting bracket, (2) Fine thread machine screws, (2) 1/2" Rubber hoses with fittings (2) Zip ties
2	Gather all of the following tools needed for the installation: 13mm socket and ratchet, Phillips screwdriver, 5/16 nut driver or flat head screwdriver, light oil
3	<p>Remove factory intake tube by loosening clamp at both ends, unplug Intake air temp sensor on tube. Remove engine cover by pulling straight up front the front.</p> 
4	<p>Remove plastic portion of the PCV line that runs from rear of engine to just under throttle body. The plastic hose is installed into two rubber ends. You may need to use pliers to loosen rubber on plastic hose.</p> 
5	<p>Find the 13mm bolt near the driver side, its right behind the large A/C line near the headlight. Remove bolt, install J&L Mounting bracket using same bolt and tighten.</p>




6 Mount J&L Oil separator to bracket with supplied screws, the fittings should be facing the driver side of the truck.

When routing the hoses, take into consideration the natural bend the hoses have. Use the natural bend to your advantage in routing the hoses easily.

With the longer of the two hoses, starting from the back of the engine route the hose under the intake box breather line, under the solenoids, under the a/c line and under the radiator hose.

Using light oil, lube the fittings (Q-Tip works well) to help slide the hose on to the fitting closest to the back of the truck. The hose is a push loc style hose, it is very tight and will not need clamps.

Now take your shorter hose, route it from the engine side under the A/C line, under radiator hose, under the radiator overflow hose and under the small A/C before the J&L can. Attach it to the fitting closest to the front of the truck.



7 Once hoses are installed. Use supplied zip ties to keep hoses together and neat.



8

9 Reinstall engine cover and intake tube.

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 4:30pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.