



**757-842-6497**  
**WWW.JLOSC.COM**



### J&L 3.0 Oil Separator Passenger Side #3108P

(2016-2023 Nissan Titan 5.6L)

To view install video: go to our website [www.Jlosc.com](http://www.Jlosc.com) and type 3108P in search box. Click on product, scroll down and click on videos.

### Installation Instructions

Please review complete instructions prior to installing.


Step#	
1	<b>Verify you have all of the following parts included in the kit:</b> (1) J&L Oil Separator, (1) J&L Mounting bracket, (2) M4 Fine thread machine screws, (2) 3/8's hose assemblies
2	<b>Gather the following tools needed for the installation:</b> Phillips screwdriver, 10mm socket, ratchet, pliers, and light oil
3	Remove Factory engine cover by pulling up at the front and sliding towards the front of the vehicle. Locate and remove factory both PCV line's squeezing clamps to release and removing it from the PCV valve and intake manifold. There is one on the driver and passenger sides. 
4	Remove clamps from factory hoses, you will reuse these clamps at the connections on the engine. One clamp on each of the shortest hoses, one clamp on the longest hose.  <p>Mount the J&amp;L bracket to the J&amp;L oil separator with supplied screws, mount bracket so the logos on the bracket and oil separator line up.</p>

- 5 Locate 10mm engine cover mounting bolts, remove bolt on passenger side. Loosen bolt on driver side. Slide J&L bracket in between manifold and engine cover bracket. Reinstall bolt, bracket should be facing straight out and retighten the bolts.



- 6 Take the shorter of the two J&L hoses. This line will run to PCV Valves on the valve covers from the "O" (OSC) side of the J&L oil separator. Start from back of engine and route long line under coolant line and breather line. Use light oil inside hose end and lightly oil connection on oil separator and PCV Valves. This will help to slide hose all the way on to their connection points. Once hose is attached slide clamp up on the PCV fittings with pliers.

Now route the longer hose from the "C" (OSC) side of the oil separator under the PCV line to manifold, under the breather line running across intake manifold and connect to PCV Valve. Be sure to lubricate these connections also for easier install. Slide clamp down on PCV once hose is attached.



- 7 Reinstall engine cover.



To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail [info@JLosc.com](mailto:info@JLosc.com) or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 4:30pm Eastern Time.

**J&L Oil Separator co. Lifetime Satisfaction Guarantee.** We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. [www.JLosc.com/warranty](http://www.JLosc.com/warranty)

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

**Return Policy:** All returns will be subject to a 10%-25% restocking fee. Please visit [www.JLosc.com](http://www.JLosc.com) for complete return policy.

**Disclaimer:** J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.