# Installation Instructions for 300106 Coated Header

Please read and understand these instructions completely prior to starting work.

CHECK TO MAKE SURE YOU RECEIVED THE PROPER PARTS FOR YOUR APPLICATION. IF YOU ARE UNSURE YOU HAVE RECEIVED THE PROPER PARTS, CALL BEFORE YOU START WORK.

**BE SURE TO WORK SAFE!** WHENEVER YOU WORK UNDER THE VEHICLE BE SURE THAT IT IS LOCATED ON LEVEL, SOLID GROUND AND IS SUPPORTED BY ADEQUATE SAFETY STANDS! **REMEMBER: HOT ASPHALT WILL NOT SUPPORT MOST JACK STANDS!** 

Many factors affect the installation of headers, some of which are broken or aftermarket motor mounts, accidents that impact the configuration of the frame, and/or the installation of different engines or aftermarket cylinder heads. Most installations require some welding. If you are uncomfortable with welding operations, we recommend that you contact a professional exhaust system specialist to install your new headers.

Attention Customers breaking in new engines: Due to the extreme heat generated during the break-in process, the appearance of the ceramic coating may be altered in certain areas. The protection characteristics and thermal barrier properties of the coating is never compromised. It is recommended that a cast iron manifold or old set of headers be used for this process.

**Notice**: The coating of these headers can be marred or scratched during installation. Please use the ceramic header installation kit that is included with this kit. This will reduce the possibility of getting scratches, nicks or discoloration of the headers while installing them.

#### DISASSEMBLY

- 1. Disconnect the negative battery cable from the battery.
- 2. If a car lift is not available, raise the vehicle 2 feet or higher and support it with adequate safety stands. Make sure the vehicle is on a flat solid surface and is stable.
- 3. Apply penetrating oil to all nuts and bolts to be removed.
- 4. Remove and mark all spark plug wires and then remove all spark plugs.

**NOTE:** Grasp the spark plug boot, not the wire, and use a twisting motion while pulling the wire from the plug.

- 5. Disconnect the head pipes from the exhaust manifolds and remove the manifolds. Depending on the application, you may be required to remove the alternator, dipstick, clutch linkage, and/or oil filter. In some cases it may be necessary to remove the starter and power steering unit. Only remove what is necessary to allow the removal of the manifolds or the installation of the headers.
- 6. Replace the spark plugs finger tight so debris will not get into the cylinders during the cleaning operation.
- 7. Remove any gasket material or any carbon deposits that remain on the head surface. The use of a gasket removal agent will ease the removal of any gasket material. We recommend the use of a sharp gasket scraper to remove the bulk of material and to finish the operation with a sanding block to provide a clean flat sealing surface.
- 8. After cleaning is complete remove the spark plugs again.
- 9. At this point it may be necessary to cut the head pipes to allow room to install the headers. If you are installing a new exhaust system you may cut the head pipes any where you choose, but if you are using the existing exhaust you need to cut the head pipes in the proper location so that they will be able to be welded to the reducers supplied with your headers.

# ASSEMBLY

- Install the headers (usually from the bottom of the vehicle, depending on the header style and vehicle model). Slide the headers into place and install a bolt at either end of the header to hold them in place. This will allow you to determine proper fit.
- Once you have determined proper fitment, install the gaskets. Install the gaskets using a <u>THIN</u> film of Ultra Copper Hi-Temp Sensor-Safe Silicone Sealer on both sides of the gasket. Install all of the header bolts supplied and hand tighten. Tighten all bolts evenly to a torque of approximately 25 ft. lbs. on 5/16" & M8 bolts and 35 ft. lbs. on 3/8" bolts.
- 3. Install any accessories that were removed during the header installation.



1-800-345-4545 jegs.com

**NOTE:** Some accessories require different brackets than stock and some require the addition of spacers between the bracket and header flange. An example would be on some Chevy applications the driver's side front bolt must use the original (factory) bolt and use the supplied spacer between the flange and the accessory bracket.

- 4. Install the reducers and determine the connection to the exhaust system.
- 5. Weld the reducers to the exhaust system and install them onto the headers utilizing the gaskets and bolts supplied.
- Install spark plugs and connect the wires to the proper plug. If the spark plugs have a lot of miles on them, now
  would be a good time to replace them. When you install the spark plugs, apply a small amount of anti-seize to
  the threads.
- 7. Check to make sure that all the wiring, brake lines, hoses, etc. are clear of the headers or any exhaust component.
- 8. Connect the battery cables.

# START THE ENGINE

Start the engine and allow it to warm up to operating temperature. Check for any unusual noises or exhaust leaks. If every thing is OK, stop the engine and tighten all bolts while the engine is still warm. **NOTE:** Check the bolts periodically to make sure they have not loosened. Re-tighten after the first 500 miles and then again at 1000 miles

#### **IMPORTANT CHECK LIST**

- Be sure that all brake lines and fuel lines are clear of headers and/or connector pipes.
- All spark plug wires, battery cables, or other electrical components should be clear of headers and/or connector pipes.
- If dipstick tube was removed, make sure it is installed properly and that the dipstick has been replaced.
- Double-check the tightness of all bolts including brackets and accessories.

#### **FINISH & MAINTENANCE**

JEGS headers and exhaust components are available with a variety of finishes including paint, chrome and ceramic coating. Some Products are sold plain (bare metal) so you can customize your own finish.

# METALLIC CERAMIC THERMAL BARRIER COATING

Our coating is simply the best available, featuring inside and out application, high thermal fatigue resistance, advanced corrosion and rust protection, reduced under hood temperature and a polished high luster silver finish. Care should be as follows.

- 1. Prior to starting the engine, wipe the header with solvent to remove oils and grease that might burn into the surface.
- 2. Avoid excessive start-up heat, particularly on a new or rebuilt engine. We recommend a used header for new engine break-in. Because of variations in each engine's state of tune, coating discoloration may occur.
- 3. Engine operating temperature is important but is not always the best indicator of exhaust temperature.
- 4. Stubborn stains can be buffed with aluminum wheel polish or gray <sup>®</sup>Scotchbrite. Avoid products which contain any abrasive compounds.



1-800-345-4545 jegs.com