

Installation Instructions for 100811 Holley/Carter/Mr. Gasket/Edelbrock Performer Mechanical Pump to Edelbrock/AFB Carb

Kit Includes:

- (1) 100516 5/8" - 20 x #6 Banjo Hose End
- (1) 100911 6' x #6 Hose
- (1) 100104 1/4" NPT x #6 Fitting
- (1) 100021 90° Hose End #6
- (1) 100106 3/8" NPT x #6 Fitting

