

Installation Instructions for 511100 Universal Silicone Engine Coolant Plumbing Kit

Installation Instructions:

1. The silicone hose can be positioned anywhere over the aluminum tube either completely or partially as shown below.
2. Finish the installation using the appropriate size hose clamp such as JEGS #555-82002 (1-1/2") and #555-82004 (1-3/4") (not included).

