

Installation Instructions for 40355 Spark Plug Flat Indexing Washers

Included are (10) washers of each thickness (0.043", 0.054", 0.064").
They are to be used with 14mm Flat-Seat Spark Plugs Only.

Installation Instructions:

1. Mark your spark plugs by drawing a line on the porcelain parallel to the ground electrode with a magic marker as shown.
2. Screw the plug into the cylinder and torque to 10 ft/lbs.
3. Note the electrode location and how many degrees it has to be rotated to be in the proper position.
4. Select the proper washer and install it on the plug. The 0.043" washers will rotate the plug counterclockwise 105°; the 0.054" washers will rotate the plug 210°; and the 0.064" washers will rotate the plug 315°.
5. Tighten to 10 ft/lbs.
6. Check to make sure the electrode is in the proper location.

Note: Use only one(1) washer per spark plug. DO NOT double stack.

Note: Washers may be reused many times, as long as they are not over tightened.

