

Installation Instructions for 50080 TBI Air Flow Enhancer



Installation Instructions:

1. Install the supplied grommet into the hole on the side of the Air Flow Enhancer.
2. Install the supplied rubber gasket around the top edge of the Air Flow Enhancer.
3. Disconnect the air intake hose from the air cleaner. Remove the air cleaner nut and remove the air cleaner assembly carefully, making sure to disconnect any hoses or wiring.
4. Disconnect the hose that is attached to the rear of the air cleaner spacer and remove the air cleaner spacer. Check the hose for cracks, etc, and replace with the supplied hose if necessary.
5. Remove the old throttle body gasket. Making sure the surface is clean install the new supplied throttle body gasket.
6. Install the appropriate supplied hose coupler (90 degree or straight) for your application into the grommet that was installed in step one(1).
7. Install the hose that was removed in step three(3) onto the hose coupler and install the Air Flow Enhancer onto the throttle body, making sure it is fully seated.
8. Reinstall the air cleaner assembly and air intake hose complete.