


## Installation Instructions for 51390 3-Duece Intake Manifold & Carburetor Package



1: Install carb mounting studs.




2: Install carb base gaskets.



3: Install center carb (one with choke).



4: Install outboard carbs. You may have to tip carbs to place them on intake.



5: Make sure all carbs are sitting flat on intake.



6: Install carb mounting nuts.



7: Once you have all carb. nuts installed, check throttle opening on each carb. then tighten nuts (caution don't over tighten).



8: Install fuel lines finger tight. Do not fully tighten until all lines are installed.



9: Continue installing fuel lines.



10: Continue installing fuel lines.




11: Once all fittings are installed finger tight, tighten with wrench.



12: Check to see that all fittings are properly tightened.



**13.** Plug hot wire onto choke cap.



**14.** Thread throttle rods into truions on center carb do not tighten locking nut at this time.



**15.** To adjust carb throttle, hold carbs full throttle and adjust rods so outboard carbs are fully open as shown.



Outboard carb must be fully open.



**16.** Place washer and wire clip in end carb throttle pins.



**17.** Tighten lock nut at this time, caution do not over tighten.



**18.** Place air cleaner studs in carbs and tighten. (Caution do not over tighten).



**19.** Place air cleaner base gaskets on all carbs.



**20.** Place air cleaner on carbs install washer and chrome nut.



Don't over tighten air cleaner nut.



Complete installation.