

Installation Instructions for 60359 Quick Connect Transmission Fitting Kit

Use the appropriate fitting wrenches for AN fittings and liberal amounts of Teflon tape or paste on pipe fittings. (**DO NOT** get any sealing compounds inside the fittings)

