

Installation Instructions for 80360, 80361 & 80362 E-Track

Installation Instructions:

1. These systems can be welded, riveted, or bolted to a trailer wall or floor. When mounting to the floor use Grade 8 bolts fastened through the trailers cross members adding additional fasteners every 3 holes.
2. Mount on a smooth flat surface. Not recommended for use on diamond plate.



1-800-345-4545 jeps.com