

Installation Instructions for 90040, 90042 & 90044 Rubber Hood/Trunk Latch

Installation Instructions:

1. First find the location for the U-Bracket that is desired (please make certain that the nipple is facing up during this step). **Do Not Drill.**



2. Once marked find the desired location for the latch bracket (Do this with the nipple facing down). **Do Not Drill.**



3. When the desired locations are marked, start by drilling the holes for the latch bracket first, by using a 3/16" drill bit.
4. As soon as the holes are drilled, install the latch by using (2) 3/16" rivets (use part number 555-82306 Not Included). Make sure the nipple is facing down in the latched position before riveting.
5. Next, drill the U-Bracket mounting bracket holes with a 3/16" drill bit, then attach with (2) 3/16" rivets. Once installed, check the tension of the latch. There should always be a pull to the latch.