

Installation Instructions for 10038 “R” Terminal Diode Kit for GM Starters

Installation

- 1.** Connect ring terminal end of wire to starter as shown
- 2.** Connect crimp connector end to the “R” terminal wire from vehicle



Kit on 555-10040 starter



Kit on 555-10021 starter



555-10038 Starter “R”
Terminal Diode Kit

This kit can be used with
other starter types
if installed as shown