

## ***Installation Instructions for 23615 Lifter Valley Vent Tubes***

### ***Lifter Valley Breather Tubes***

Jeg's 6061 T-6 aluminum breather tubes improve ventilation and prevent oil drainback across the camshaft in race only applications.

### ***Installation***

During block preparation tap the oil return holes by using 1/4" NPT (tapered) tap. Always clean the block thoroughly prior to any assembly.

