

Installation Instructions for 23715 High Flow Oil Filter Adapter

Note: This oil filter adapter fits most small block and Big Block (Mark IV) Chevy engines that use 5/16"-18 threads to hold the OEM oil filter bypass adapter in place. New big block Mark V and VI engines don't have the recessed oil filter boss and cannot use this adapter.

This adapter is designed for use with oil filter 555-32720 (Wix® # 51268R) – high flow racing oil filter. The oil filter is available separately and is not included w/ the adapter.

Parts List:

- (1) Oil Filter Adapter (*Steel*)
- (1) Oil Filter Adapter Plate (*Aluminum*)
- (3) O-Rings (*Small, Medium, Large*)
- (1) Snap Ring
- (2) 5/16"-18 x 3/4" Long Stainless Steel Cap Screws
- (2) 5/16" Stainless Steel Lock Washers

Installation Instructions:

- Remove the OEM oil filter bypass / adapter assembly.
- Clean the block in the oil filter pocket.
- Install the medium o-ring in the bottom of the Oil Filter Adapter (*Steel Piece*).
- Install the small o-ring that goes below the threaded area on the Oil Filter Adapter (*Steel Piece*) – Be careful not to damage the o-ring when installing it in the groove that is near above the threads.
- Bolt the Oil Filter Adapter to the block in the pocket with the two cap screws & lock washers.
- Work the large o-ring in the groove on the Oil Filter Adapter Plate.
- Add some oil to the small o-ring before assembly.
- Gently push the Oil Filter Adapter Plate over the Oil Filter Adapter and down into the outer pocket on the block.
- Install the snap ring to hold the assembly together.
- If needed you can use the oil filter to push the Oil Filter Adapter Plate down over the Oil Filter Adapter & then remove it to install the snap ring.

