

Installation Instructions for 60600 U-Joint Race Girdle

Installation Instructions:

1. Remove existing u-joint straps.
2. Push driveshaft towards transmission to gain clearance for installation of girdle and fasteners.
3. Place 3/8" bolts through holes in girdles and secure over u-joint bearing caps with the flange nuts.
4. Tighten bolts evenly making sure that the girdles come down straight and not cocked to one side. Torque fasteners to 45 ft/lbs.

If needed, grind or file the yoke – DO NOT GRIND THE GIRDLES!

PARTS LIST

- 2 – Aluminum Girdles
- 4 – 3/8"-24 Counterbore Bolts
- 4 – 12-point Flange Nuts



1-800-345-4545 jeps.com