

## ***Installation Instructions for 157300 TV Cable Corrector for Holley Carburetor***

### **Installation Instructions:**

1. Disconnect the TV cable and main carburetor linkage cable
2. Remove the TV stud and main linkage stud from carburetor.
3. To install the TV corrector bracket, face the stud on the corrector bracket away from the carburetor. Line up the bottom hole in the corrector bracket with the original TV stud hole on the carburetor linkage. Loosely fasten using a bolt, washer and nut.
4. Line up the top hole in the corrector bracket with the original throttle linkage stud hole in the carburetor linkage. Insert the original throttle linkage stud into the hole and secure it with the nut. If the original throttle stud has been relocated use the additional bolt, washer and nut included in the kit as shown in the illustration below.
5. Tighten up the stud and bolt. Attach the throttle linkage cable to the stud. The TV cable should be attached to the stud on the corrector bracket.

