

## ***Installation Instructions for 30970, 30971, 30972, 30980, 30981 & 30982 Stainless Steel Exhaust Tips***

### **MOUNTING INSTRUCTIONS:**

JEGS Thunder Exhaust Tips can be attached by a universal muffler clamp, exhaust tube clamp, or a hanger. Visit [www.jegs.com](http://www.jegs.com) for a wide selection of clamps. For custom applications the exhaust tip may also be welded on. It is recommended that the vertical exhaust tube hanger be within three feet of the joint of the exhaust tip.

If the vehicle is not already equipped with a vertical exhaust tube hanger, one may have to be attached to the underbody or frame. Do not attach exhaust tip to any body part or the frame of the vehicle.



**1-800-345-4545 [jegs.com](http://jegs.com)**