

***Installation Instructions for 60552
Rear Control Arm Bolt Kit
for 1979-1993 Mustang***

Installation Instructions:

The shorter 90mm (3.54") bolts are used on the upper control arms. The longer 100mm (3.94") bolts are used in the lower control arms.



1-800-345-4545 jeps.com