

## ***Installation Instructions for 60601, 60602, 60603, 60604 & 60605 U-Joint Girdles***

### **Installation Instructions:**

On some applications where original equipment included factory installed straps, it is necessary to drill out the yoke to accept the through bolts.

1. Press clamp down on bearing cap and check for at least 0.010" crush at parting line. Be sure to grind or file yoke if needed – DO NOT GRIND CAP!
2. When through bolts are tightened be sure clamp comes down straight and not cocked over to one side.

### **PARTS LIST**

- 2 – Aluminum Caps
- 4 – Socket head caps screws
- 4 – Nuts
- 4 – Washers

Part No. 60604 does not come with any washers.



**1-800-345-4545 [jeps.com](http://jeps.com)**