

# Installation Instructions for 61630 Universal Delay Box Mount

## Installation Instructions:

1. Fit all the components together as shown below to determine the desired location in the vehicle.
2. Furnished in this kit is a short tube with a pre-drilled hole for a 1/4" quick release pin. Weld this short tube to the chassis in the desired location with pre-drilled hole facing up.
3. Fit remaining components back together and cut the short and long legs of the formed tube to the desired length.
4. Lay the mounting plate on a flat surface and place the short leg of the formed tube into the center of the mounting plate in the desired angle. Weld the bent tube to the mounting plate on this back side all around.
5. Slide the long leg of the formed tube into the short tube and set the angle the delay box faces as desired. Using a letter 'F' drill bit and the pre-drilled hole in the short tube as a guide, drill through the bent tube to create the hole for the quick release pin.

