

1. Install bushings into the springs using polyurethane-safe grease. If applicable, install the sleeves into the bushings.
2. Mount the springs to the vehicle. The end with the military wrap should be at the front.
3. Check to make sure the long side of the bolts on the spring clamps are pointed towards the inside of the vehicle.
4. Fully cycle the suspension and verify that no part of the springs interfere with other suspension components (e.g. shocks). Also verify that the brake lines are long enough and do not stretch at maximum droop or get pinched by other components. In some instances, leaf spring clamps may need to be removed or relocated to avoid interference with other components.
5. If you have any questions or concerns, please e-mail your questions to [tech@trail-gear.com](mailto:tech@trail-gear.com) or call us at 559.549.6737.