

Installation Instructions for 027-11203K3 Fitting Kit for Aeromotive Fuel Pump 11203

Kit Includes:

(2) 555-15982 3/8" NPT to 1/2" Hose (Brass) Fittings

NOTE: Use Teflon tape or sealant on fittings before installation.

