

Installation Instructions for 027-13202K1 Fitting Kit for Aeromotive Regulator 13202

Kit Includes:

- (2) 027-15618 #8 Port Plugs
- (2) 555-110167 #10 Port to #10AN Inlet & Return Fittings
- (4) 555-110163 #8 Port to #8AN Outlet Fittings

NOTE: Always lubricate threads and o-ring on port fittings before installation.

