



Installation Instructions

For Part Numbers:

- 200-102 700-420 Airaid Oiled Media Filter
- 201-102 701-420 SynthaMax Dry Media Filter - Red
- 202-102 702-420 SynthaMax Dry Media Filter - Black
- 203-102 703-420 SynthaMax Dry Media Filter - Blue

- 1999-00 Cadillac Escalade
- 1996-99 Chevrolet/GMC Pickup C/K 1500
- 1996-00 Chevrolet/GMC Pickup C/K 2500, C/K 3500
- 1996-99 Chevrolet/GMC Suburban C/K 1500, C/K 2500
- 1996-00 Chevrolet Tahoe/GMC Yukon
- 4.3L V6, 5.0L V8, 5.7L V8



Component Identification

1.	Airaid Premium Filter	1
2.	3.5 x 3.5 Stainless Coupler	1
3.	Tube Assembly	1
4.	5/16-18 x 3/4" Hex Bolt	2
5.	5/16" Nut	2
6.	5/16" Washer	2
7.	Bracket	1

Full color instructions can be viewed on our web site at Airaid.com. Use the **Product Search** function to find your part number, and click **View Details**.

I DISCONNECT NEGATIVE (-) BATTERY CABLE.

II Remove air filter housing.

- a) Unsnap lid, open, unhinge and set aside.
- b) Remove filters and set aside.
- c) Gently lift up the Mass Air Flow (M.A.F.) sensor assembly and place it rearward out of the way.
- d) Remove the air filter-housing base. Grip from the hinge (engine) side and lift straight up to remove.
- e) Remove the air filter housing base bracket. Use a 13mm wrench to remove the bolt UNDER the fender.

III Remove M.A.F. to Air box adapter.

- a) Disconnect the Manifold Air Temperature (M.A.T.) sensor wire.
- e) Remove the 90° adapter from the inlet of the M.A.F. Loosen the clamp and pull off.
- b) Remove the M.A.T. sensor from the adapter. Be gentle and save for reinstallation.
- c) Remove the M.A.T. grommet from the adapter. Save for reinstallation.
- d) BE VERY GENTLE WITH THE M.A.F!! It is very fragile!!

IV Install the new powder coated 90° filter adapter.

- a) Install, using supplied hardware, onto the two existing holes in the fender. The backing plate installs from the bottom side of the fender.
- b) Slide the 3.5" stainless coupler onto the adapter.
- c) Insert the M.A.F. into the coupler. Align the assembly and carefully step tighten the stainless coupler.
- d) Install the M.A.T. grommet in the adapter hole. Now, carefully insert the M.A.T. and reconnect the wire.
- e) Tighten the filter adapter on the fender.

*** Note: Some '98's have been equipped with A.I.R. (smog) pumps. If you have a 1" hose remaining after the install, then you have this pump and will require an additional breather K&N Part # 62-1040.**

V Finishing up Airaid Installation.

- a) Check for any foreign objects in the airflow path.
- b) Reconnect battery cable. Double-check your work. Have fun!!





WARNING! If your vehicle has a Vehicle Emission Control Information decal affixed to the factory airbox, a new replacement label must be obtained and installed in a readily visible position in the engine compartment in order to remain CARB compliant. Failure to do so will prevent the vehicle from passing a smog check. Replacement labels can be ordered from your local dealership. Regulations state that the VECI label shall not be affixed to any equipment which is easily detached from the vehicle. Label placement, under the hood on a painted surface is recommended.

Thank you for purchasing the Airaid Intake System. Contact Airaid @ (800) 498-6951 8:00 AM - 5:00 PM MST weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid Intake System was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, contact Airaid. The air filter element is protected from direct exposure to water and debris; care should be taken not to drive through deep water. WATER INGESTION IS THE DRIVERS RESPONSIBILITY! The air filter is reusable and should be cleaned periodically.

FILTER IDENTIFICATION

700-420 Airaid Oiled Media
702-420 Airaid SynthaMax Dry Media - Black

701-420 Airaid SynthaMax Dry Media - Red
703-420 Airaid SynthaMax Dry Media - Blue

**For your Oiled media filter
we suggest using the AIRAID
Filter Tune-Up Kit!**



Do Not Oil



Synthamax Air Filters do not require oil. Service air filter as needed by cleaning with common non-petroleum all-purpose household cleaner and water. Simple Green®, Formula 409® or equivalent works great. Apply cleaner to outside of air filter and allow to soak. Then flush filter clean from the inside out with a garden hose and repeat steps if necessary. Do not apply high pressure water or air to clean filter. Allow filter to air dry and reinstall.

P/N 790-551 Aerosol Spray
P/N 790-550 Squeeze Spray

