



INSTALLATION INSTRUCTIONS
#300-944 MODULAR INTAKE TUBE (MIT)
OR
#300-744 AIRAID JR. KIT
04-06 DODGE DURANGO 4.7L

Thank you for purchasing the Airaid MIT or Airaid Jr. Kit. Please read the instruction manual carefully before proceeding with the installation. Contact Airaid @ (800) 498-6951 8:00 AM - 5:00 PM MST weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid MIT or Airaid Jr. Kit was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, contact Airaid. The air filter element is protected from direct exposure to water and debris; care should be taken not to drive through deep water. WATER INGESTION IS THE DRIVERS RESPONSIBILITY! The air filter is reusable and should be cleaned using the Airaid Filter Tune-Up Kit periodically.

Thank you for selecting Airaid.



Packing List:

KIT944T	Modular Intake Tube	1
KITRDCR01	Silicone Hose Reducer	1
KITHUMPHS03	Urethane Hump Hose	1
KIT944HP	Hardware & Instructions	1
- KITGRMT03	Rubber Grommet	1

Packing List (cont'd):

- KITHS52	#52 Hose Clamp	1
- KITHS56	#56 Hose Clamp	1
- KITHS60	#60 Hose Clamp	2

Tools Required for this Installation:

- Flat Head Screwdriver
- 10mm Deep Socket

Installation Instructions. Read Me!



1. Disconnect the negative battery cable and remove the breather hose from the factory air box lid.



4. Disconnect the factory electrical connector from the factory air temperature sensor.



7. Install the reducer hose and a #52 hose clamp onto the throttle body. Install a #56 hose clamp onto the other side of the reducer.



2. Loosen the two hose clamps on each end of the factory intake tube.



5. Loosen the two 10mm bolts mounting the factory air box to the intake manifold and remove from vehicle.



8. Slide the urethane hump hose onto straight end of Airaid intake tube with two #60 hose clamps. (*Note: Leave hose clamps loose until final assembly.*)



3. Unsnap the factory silencer box from the fan shroud and remove the factory tube assembly from the vehicle.



6. Turn the air temperature sensor $\frac{1}{4}$ turn and remove from the air box. Retain sensor for later use.



9. Install Airaid intake tube assembly by connecting the Airaid hump hose onto the factory air box lid and the other end onto the Airaid reducer hose. Tighten all hose clamps.



10. Install the supplied rubber grommet and factory air temperature sensor into the Airaid intake tube. Then, reconnect the factory electrical connector onto the sensor. Lastly, reconnect the factory breather hose to the air box lid.

11. If you purchased the Airaid Jr. Kit P/N 300-744, replace the factory air filter with the Airaid Premium Filter included in the Kit.


12. Double check your work to be certain that all nuts, bolts, and clamps are securely fastened.

13. Reconnect the negative battery cable.

Before



After!



Don't Forget Your AIRAID Filter Tune-Up Kit!



P/N 790-550

Instructions Revision
Date: 06/20/07