

Create a picture of putting in the  
plug before next print – kd 12/5/02



**P/N: 800-376**

### **Application: Dodge Pick-Up 89-93 W/Cummins Engine**

Congratulations! You are now the proud owner of an AIRAID premium filter. This filter will last the lifetime of your vehicle if it is properly cared for. This filter is a direct replacement for your stock filter. Please follow the installment directions closely to ensure the correct fit and proper seal of the AIRAID premium filter.

- Loosen the hose clamps on the intake that connects the air box to the engine.
- Remove the bolts from the lid of the air box.
- Carefully remove the air box lid, and then remove the stock filter.
- Install the AIRAID premium filter in its place.
  - Note: If your model is from '89-'92 you **MUST** remove the rubber plug so that the filter can be mounted with the existing bolt.
  - Note: If you own a '93 model, you **MUST** retain the rubber plug and replace the air box lid after installing the filter. Reach through the center of the air box lid to confirm that the filter is properly seated before retightening the lid.
- Retighten all of the bolts to the lid, and replace any missing bolts.
- Reconnect the hose from the engine to the air box lid.
- Start your engine and check for any problems or leaks.

