



Technical Support Line: (952) 985-5675 Email: sales@QA1.net

INSTALLATION INSTRUCTIONS

QA1 P/N 52854 '78-'88 GM G-Body High-Clearance Front Sway Bar

TOOLS AND SUPPLIES REQUIRED

Floor Jack

Jack Stands

Ratchet & Socket Set

• Torque Wrench

REMOVAL-

- 1. Raise and support the vehicle with jack stands on a level surface.
- 2. Remove the factory sway bar (if equipped)

INSTALLATION-

- 1. Lay the mounting bracket and sway bar on a flat surface in the orientation shown. (Figure 1) The sway bar sticker should be upside down.
- 2. Install 3/8" x 1" hardware up through the mounting bracket.



- 3. Install the bushings around the sway bar with the bushing straps over the top. (Figure 2)
- Attach the sway bar to the bracket with one washer and nyloc nut through the bushing straps. Loosely starting all four connections will aid in getting them started.
- Install 3/8" x 1" bolts with one washer per connection down through the mounting bracket. (Figure 2)




6. Flip the sway bar with bracket over and bring into position on the vehicle with the legs of the sway bar above the lower trailing arms. (Figure 3)



7. Thread the four bracket bolts into the original sway bar mounting points. (Figure 4) Do not tighten this hardware at this time.



8. Install the sway bar end links to the sway bar and control arm with the bar and control arms between the sets of bushings. (Figure 5 & 6)



- 9. With the suspension compressed, tighten the sway bar end links until the bushings compress to the same diameter as the washers.
- 10. Tighten all 3/8" hardware to 31 lb. ft. (Figure 7)



Technical Support Line: (952) 985-5675 Email: sales@QA1.net



QA1 is dedicated to providing quality support and instructions. We employ passionate racers and car enthusiasts that know our products and the industry to better serve you.

CHECK US OUT ON YOUTUBE!

- Frequently Asked Questions

- You Tube
- Quick Tips
- Install Information
- Tuning and Repair Guides
- Other Technical Infortmation

youtube.com/qa1tech



www.qa1.net/tech



READ ALL INSTRUCTIONS CAREFULLY AND THOROUGHLY PRIOR TO STARTING INSTALLATION. PRODUCTS THAT HAVE BEEN INSTALLED ARE NOT ELIGIBLE FOR RETURN. USE THE PROPER JACKING LOCATIONS. DEATH OR SERIOUS INJURY CAN RESULT IF INSTRUCTIONS ARE NOT CORRECTLY FOLLOWED. A GOOD CHASSIS MANUAL, AVAILABLE AT YOUR LOCAL PARTS STORE, MAY ALSO AID IN YOUR INSTALLATION.

• DISCLAIMER / WARRANTY •

QA1 WARRANTS THAT THE PRODUCTS WILL BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP FOR ONE YEAR FROM DATE OF SALE TO THE ORIGINAL PURCHASER. QA1 MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. QA1 SHALL HAVE NO OBLIGATION UNDER THE FOREGOING WARRANTY WHERE THE DEFECT IS THE RESULT OF IMPROPER OR ABNORMAL USE, YOUR NEGLIGENCE, VEHICLE ACCIDENT, IMPROPER OR INCORRECT INSTALLATION OR MAINTENANCE, NOR WHEN THE PRODUCT HAS BEEN REPAIRED OR ALTERED IN ANY WAY. QA1'S LIABILITY IN THE CASE OF DEFECTIVE PRODUCTS SUBJECT TO THE FOREGOING WARRANTY SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT, AT QA1'S OPTION, OF THE DEFECTIVE PRODUCTS.

THE USER UNDERSTANDS AND RECOGNIZES THAT RACING PARTS, SPECIALIZED STREET ROD EQUIPMENT, AND ALL PARTS AND SERVICES SOLD BY QA1 ARE EXPOSED TO MANY AND VARIED CONDITIONS DUE TO THE MANNER IN WHICH THEY ARE INSTALLED AND USED. QA1 SHALL BEAR NO LIABILITY FOR ANY LOSS, DAMAGE OR INJURY, EITHER TO A PERSON OR TO PROPERTY, RESULTING FROM THE INSTALLATION, DIRECT OR INDIRECT USE OF ANY QA1 PRODUCTS OR INABILITY BY THE BUYER TO DETERMINE PROPER USE OR APPLICATION OF QA1 PRODUCTS. WITH THE EXCEPTION OF THE LIMITED LIABILITY WARRANTY SET FORTH ABOVE, QA1 SHALL NOT BE LIABLE FOR ANY CLAIMS, DEMANDS, INJURIES, DAMAGES, ACTIONS, OR CAUSES OF ACTION WHATSOEVER TO BUYER ARISING OUT OF OR CONNECTED WITH THE USE OF ANY QA1 PRODUCTS. MOTORSPORTS ARE DANGEROUS; AS SUCH, NO WARRANTY OR REPRESENTATION IS MADE AS TO THE PRODUCT'S ABILITY TO PROTECT THE USER FROM INJURY OR DEATH. THE USER ASSUMES THAT RISK!