



# BBK Short H-Pipes/X-Pipes For Full-Length Headers



## Special Tools

### Required:

- No special tools required

## Install Time:

Approximately  
30 mins

## Difficulty:

1 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

### STEP 1

- After installing your new BBK full-length headers, you can now install the matching short H-Pipe/X-Pipe by simply bolting it in place of the old H-Pipe Assembly.\*

### STEP 2

- Using the washers and nuts supplied with your full lengths stud kit, mount the front H-Pipe/X-Pipe flanges to the header collectors.

### STEP 3

- Using the supplied hardware, bolt up the BBK H-Pipe/X-Pipe.
- ***NOTE!!! Be sure to add a small amount of anti-seize to the top thread of each oxygen sensor using the supplied anti-seize packet. As you thread the oxygen sensor back into the part the anti-seize will spread evenly throughout the threads.***

### STEP 4

- Reconnect the factory air tube if installing catalyst equipped pipes.

**\*It may be necessary to use some WD-40 to aid in the hanger installation. Due to the metal to rubber slide mount these units can be sticky.**



Join our Facebook page  
[www.facebook.com/bbkperformance](http://www.facebook.com/bbkperformance)



Follow us on Twitter  
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube  
[www.youtube.com/bbkperformance](http://www.youtube.com/bbkperformance)

[WWW.BBKPERFORMANCE.COM](http://WWW.BBKPERFORMANCE.COM)

For any questions, email us:  
[tech@bbkperformance.com](mailto:tech@bbkperformance.com)

installation instructions

1

**IMPORTANT:** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-005