



# BBK Phenolic Spacer Kits

Part # 1506,1508,1520,1530,1549



Special Tools

Required:

- No special tools required

Install Time:

Approximately  
1 Hour

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

### STEP 1

- Disconnect the throttle duct hose from the throttle body.

### STEP 2

- Disconnect the throttle linkage from the throttle body and also the kick-down linkage if applicable.

### STEP 3

- Disconnect the wire connectors from the upper manifold and also the vacuum lines on the underside of the upper intake.

### STEP 4

- Remove the cover plate from the upper intake if equipped. Next remove the six bolts from the upper intake manifold.

### STEP 5

- Lift off the upper intake and discard the gasket, also making sure both surfaces are free from dirt and grease.

### STEP 6

- Next install the phenolic spacer by placing a new gasket on both sides of the spacer.

### STEP 7

- Use the new bolts provided and tighten in a criss-cross pattern beginning with the center bolts.

### STEP 8

- Next simply reverse the previous steps.



Join our Facebook page  
[www.facebook.com/bbkperformance](http://www.facebook.com/bbkperformance)



Follow us on Twitter  
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube  
[www.youtube.com/bbkperformance](http://www.youtube.com/bbkperformance)

[WWW.BBKPERFORMANCE.COM](http://WWW.BBKPERFORMANCE.COM)

For any questions, email us:  
[tech@bbkperformance.com](mailto:tech@bbkperformance.com)

installation instructions

1

**IMPORTANT:** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-003