1997-03 Ford F-150/Expedition/Lightning 4.6L/5.4L

Shorty Headers

Part # 3515,35150,3516,35160,3518,35180



Special Tools

Install Time:

Required:

Approximately 2 Hours

 No special tools required

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

NOTE!!! WILL NOT FIT F-250 OR SUPER DUTY!!!

STEP 1

Disconnect the negative battery terminal.
 Remove the front fender liners/splash guards.
 These are secured by push pin type fasteners.

STEP 2

- Disconnect the EGR fitting from the driver side manifold where applicable. <u>NOTE!!!</u> On 4x4 Models- Set the parking brake first! Then unbolt the front drive shaft from the front differential where it connects near the driver side exhaust collector.
- Disconnect any oxygen sensors that attach the stock exhaust manifolds.

STEP 3

 Remove the nuts that attach the mid pipe to the factory exhaust manifolds. Unbolt and remove the factory exhaust manifold and the gaskets.

STEP 4

 If necessary, transfer the EGR Fitting and oxygen sensors from the factory manifolds to the BBK Headers.

STEP 5

 Install the supplied collector studs onto the BBK Headers. Install the BBK Headers using the supplied gasket.

STEP 6

 Re-connect the mid pipes, and tighten the collector flanges using the supplied hardware.
 Plug in all the oxygen sensors.

STEP 7

 Re-connect and tighten the EGR Fitting if applicable. Re-connect drive shaft on 4x4 Model.

STEP 8

Re-install fender liners/splash guards. Reconnect the negative battery terminal.
 NOTE!!! To prevent exhaust leaks after installation, BBK recommends that you go back and re-tighten the header bolts after 100 miles and that you add them to your regular maintenance checklist.



Join our Facebook page www.facebook.com/bbkperformance





Check us out on Youtube www.youtube.com/bbkperformance





For any questions, email us: tech@bbkperformance.com

installation instruction

