



Part # 4005,40050- 1999-04 GM Truck 4.8L & 5.3L Part # 4006,40060- 1999-09 GM Truck 6.0L Part # 4007,40070- 1996-98 GM Truck 5.0L & 5.7L

Full Size Truck Headers

Special Tools

Install Time:

Required:

Approximately 1 hour 30min

No special tools

are required

Difficulty:

2 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

Disconnect the negative battery terminal.

STEP 2

From underneath the vehicle, remove the nuts that attach the Y-Pipe to the factory exhaust manifolds

STEP 3

Remove any EGR or air lines going to the exhaust manifolds. Unplug the oxygen sensors. Unbolt and remove the factory exhaust manifolds and the stock gaskets.

STEP 4

Clean any old gasket material off of the cylinder head, use a scrapper if necessary.

STEP 5

Using the factory hardware and the Supplied Gaskets install the BBK Headers.

STEP 6

Attach the Y-Pipe to the BBK headers using the factory hardware.

STEP 7

Using the supplied hardware, gaskets, and block-offs connect the EGR and AIR fittings to the BBK Headers where applicable. NOTE!!! Be sure to apply a small amount of the supplied anti-seize on the threads.

STEP 8

After driving the vehicle and allowing it to cool a few times, go back and re-tighten the header bolts.



Join our Facebook page www.facebook.com/bbkperformance





Check us out on Youtube www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM



For any questions, email us: tech@bbkperformance.com

