

IMPORTANT

INSTRUCTION RP20236

1. ASSEMBLE SEAL ONTO BUSHING AS SHOWN
2. THREAD ARM ONTO BRACKET STUD
3. BOTTOM OUT ARM AND BACK OFF ONE FULL TURN
4. INSTALL ON CAR
5. GREASE ARM

