13108 / RRH13108

01-07 CHEVY/GMC HD PICKUPS 6"BED

11/12/2012

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 6,000 LBS. TRAILER WEIGHT & 600 LBS. TONGUE WEIGHT. GROSS LOAD CAPACITY WHEN USED AS A WEIGHT DISTRIBUTION HITCH: 10,000 LBS. TRAILER WEIGHT & 1,000 LBS. TONGUE WEIGHT

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

TEM QTY				Parts List	
1 4 (MS-SP1	ITEM	QTY			
2 4 HPN 1213 HEX FLANGE MUT 3 4 1/2-13 x 13/4 CARRIAGE BULT 4 4 MT-2 x 40mm LG HEX BOLT 5 2 9/16 LICK WASHER LAT WASHER 6 2 9 1/6 WASHER FLAT WASHER 7 2 9/16 "CONICAL WASHER CONICAL TOOTHED WASHER DRIVER SIDE FRAME RAIL DRIVER SIDE FRAME RAIL HTCH WEIGHT: 43 LBS. INSTALL TIME: 30 MNUTES INSTALL TIME: 30 MNUTES INSTALL TIME: 30 MNUTES INSTALL MOTES:					
4 M42 x 40mm LG. HEX BOLT 5 2 916 WASHER FLAT WASHER 7 2 916 CONICAL WASHER CONICAL TOOTHED WASHER THAT WASHER FRAME RAIL A M42 x 40mm LG. HEX BOLT FRAME RAIL PASSENGER SIDE FRAME RAIL PASSENGER SIDE FRAME RAIL EXISTING WELDING A M17CH WEIGHT: 43 LBS. INSTALL TIME: 30 MINUTES INSTALL MOTES:	2	4	HFN 1213	HEX FLANGE NUT	
5 2 9/16 LOCK WASHER 6 2 2 9/16 WASHER FLAT WASHER FLAT WASHER CONICAL WASHER CONICAL TOOTHED WASHER 7 2 9/16 CONICAL WASHER CONICAL TOOTHED WASHER DRIVER SIDE FRAME RAIL DRIVER SIDE FRAME RAIL HITCH WEIGHT: 43 LBS. INSTALL TIME: 30 MINUTES INSTALL NOTES:	3	4	1/2-13 x 1 3/4	CARRIAGE BOLT	
6 2 9_16 WASHER FLAT WASHER CONICAL TOOTHED WASHER 7 2 9/16 CONICAL WASHER CONICAL TOOTHED WASHER PRASERNOR SIDE FRAME RAIL PRASERNOR SIDE FRAME RAIL PRASERNOR SIDE FRAME RAIL PRASERNOR SIDE FRAME RAIL A SIDE FRAME RAIL PRASERNOR SIDE FRAME RAIL PRASERNOR SIDE FRAME RAIL A SIDE FRAME RAIL PRASERNOR SIDE FRA	4	4	M14-2 x 40mm LG.	HEX BOLT	
DRIVER SIDE FRAME RAIL ONICAL TOOTHED WASHER ONICAL TOOTHED WASHER	5	2	9/16	LOCK WASHER	12.
DRIVER SIDE FRAME RAIL ONICAL TOOTHED WASHER ONICAL TOOTHED WASHER	6	2	9_16 WASHER	FLAT WASHER	PASSENGER SIDE
DRIVER SIDE FRAME RAIL OF THICH WEIGHT: 43 LBS. INSTALL TIME: 30 MINUTES INSTALL NOTES: INSTALL NOTES:	7	2	9/16" CONICAL WASHER	CONICAL TOOTHED WASHER	FRAME RAIL
INSTALL NOTES:		FR.	ITCH WEIGHT: 43 LBS.		EXISTING WELDNU
					All I
NO DRILLING REGUINED					4
		140	O DIVILLING HEQUINED		

INSTALLATION STEPS

- 1) Remove the 14mm hex bolt from each end of the frame.
- 2) Remove and relocate the ground wire and ground wire bolt on the driver's side frame rail.
- 3) Raise the hitch into position and install the fasteners as shown.
- 4) Torque all 1/2" fasteners to 110 lb.-ft. and all 14mm fasteners to 126 lb.-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.