

55309

KIA SEDONA

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

7/29/08



English

1. Open the rear hatch of the vehicle. Remove the rear threshold plate by carefully pulling off each screw cap (7 approx.) and removing the screws holding it in place. [A] [B]


2. Partially remove the side rear trim panels by first removing the screw on the threshold and the two cargo net brackets on each side of the vehicle. [C] [D] [E]

3. Beginning with the driver's side, the taillight wiring harness will be located inside the square hole near the vehicle threshold. Being careful of the sharp edges in the hole, there may be a gray piece of foam you have to take out in order to see the wire harness. [F] Carefully pull the black coated wire loom from the hole to expose the white connectors. [G] Separate the connectors and insert the T-Connector with the Yellow wire between the separated halves and lock into place. [H] Route 4-flat behind trim panel and out through the jack storage compartment.

Español

Français

English

4. Route the connectors with the Green wire behind the passenger side trim panel. The wire harness will be located half way up, just left of the seat belt retractor.  Separate the halves and plug the T-Connector with the Green wire between the separated halves and lock into place.

7. Locate a suitable grounding point. Drill a 3/32" hole and secure the white wire using the eyelet and screw provided. Do not drill into any exposed surfaces.

8. Replace all trim panels removed during installation. Store 4-flat in jack storage compartment when not in use.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and or personal injury.

Español

Français

