

56083

LEXUS RX 350
LEXUS RX 450H

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

4/28/09



English

1. Locate the vehicles factory tow harness under the vehicle on the drivers side frame rail location (S5). [A]

2. Remove the protective cap and save. [B]
Insert the harness connector into vehicles harness connector make sure the connector is fully inserted with locking tabs in place. [C]

3. Route the 4-flat to the center of the vehicle along the backside of the bumper and secure in a convenient out of the way location. [D] Secure any loose wires with the cable ties provided.

4. Some models may need to be programmed to accept wiring harness. This must be done by a dealer.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.