

57000

NISSAN TITAN

NISSAN ARMADA

WIRING LOCATION GUIDE

GUÍA DE UBICACIÓN DEL CABLEADO

IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

1/13/2011

English

1. Locate the vehicle's relay panel on the passenger side under the hood near the battery (A).
2. Remove the relay panel's cover, taking care not to damage the locking tabs.
3. Insert the blue relays into the positions labeled "TRAILER TURN RH" and "TRAILER TURN LH".
4. Insert the brown relay into the position labeled "TRAILER TOW NO. 2".

Note:

For vehicles not equipped with the factory OEM 7-Way, use CURT 55774 or similar.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813



