



509 Hemlock St  
Phillipsburg, PA 16866  
Ph- 814.343.6315 Fax- 814.343.6318  
**Installation Instructions**  
support@umiperformance.com  
www.umiperformance.com

### 1993-2002 GM F-Body Shock Tower Brace Item # 2005, 2006 & 2007

1. Under the hood locate (2) shock tower nuts on both the passenger and drivers side of vehicle.
  2. Using a 15mm socket or wrench (depending on vehicle) remove all (4) nuts and save for later use. Newer F-Body models may have an extra nut on the passenger side inner shock bolt that retains an A/C line bracket that must be removed.
  3. Note: On older F-Body models there is an A/C sensor on the passenger side that must be removed to complete the install. It has a release valve so don't worry about Freon loss.
  4. Position the UMI brace over one side and lower it over the opposite side. There are (2) brake lines that will need slightly pushed over in order to install brace. Use extreme caution when pushing on brake lines.
- Note: 93-02 V6 Models Item # 2007-** This install may require help from a partner to prevent marking or scratching the brace. Begin install starting at the passenger side, have a partner help pull the A/C lines out of the way to slide brace into place. Once passenger side is installed slide drivers side over studs while slightly pushing the brake lines over.
5. Once brace is in place install the supplied washers and nuts from step 2. A 15mm wrench will be needed to tighten the (2) inner nuts and a socket can be used on the (2) outer nuts, torque all (4) nuts to 32 ft. lbs.
  6. Reinstall the A/C sensor from Step 3.

Thank You for Putting Your Trust in a UMI Performance Product!  
[www.umiperformance.com](http://www.umiperformance.com)



509 Hemlock St  
Phillipsburg, PA 16866  
Ph- 814.343.6315 Fax- 814.343.6318  
**Installation Instructions**  
support@umiperformance.com  
www.umiperformance.com

### 1993-2002 GM F-Body Shock Tower Brace Item # 2005, 2006 & 2007

1. Under the hood locate (2) shock tower nuts on both the passenger and drivers side of vehicle.
  2. Using a 15mm socket or wrench (depending on vehicle) remove all (4) nuts and save for later use. Newer F-Body models may have an extra nut on the passenger side inner shock bolt that retains an A/C line bracket that must be removed.
  3. Note: On older F-Body models there is an A/C sensor on the passenger side that must be removed to complete the install. It has a release valve so don't worry about Freon loss.
  4. Position the UMI brace over one side and lower it over the opposite side. There are (2) brake lines that will need slightly pushed over in order to install brace. Use extreme caution when pushing on brake lines.
- Note: 93-02 V6 Models Item # 2007-** This install may require help from a partner to prevent marking or scratching the brace. Begin install starting at the passenger side, have a partner help pull the A/C lines out of the way to slide brace into place. Once passenger side is installed slide drivers side over studs while slightly pushing the brake lines over.
5. Once brace is in place install the supplied washers and nuts from step 2. A 15mm wrench will be needed to tighten the (2) inner nuts and a socket can be used on the (2) outer nuts, torque all (4) nuts to 32 ft. lbs.
  6. Reinstall the A/C sensor from Step 3.

Thank You for Putting Your Trust in a UMI Performance Product!  
[www.umiperformance.com](http://www.umiperformance.com)

**1993-2002 GM F-Body  
Shock Tower Brace  
Item # 2006**

**1993-2002 GM F-Body  
Shock Tower Brace  
Item # 2006**