

# IMPORTANT WARRANTY & INSTALLATION INSTRUCTIONS ATTACHED

Please Forward All Attached Information to Consumer Warranty Not Valid Unless Returned to CORSA Performance

We ask that you take a few moments to complete our warranty registration form:

TO ACTIVATE YOUR WARRANTY GO TO: CORSAPERFORMANCE.COM/WARRANTY



For Full-Color Installation Instructions, Please Visit: CORSAPERFORMANCE.COM and Search by Part Number

Please be sure to review the enclosed instructions prior to beginning the installation process. If you have any questions about the enclosed parts, instructions or encounter a problem during installation:

CALL CORSA PERFORMANCE TECHNICAL ASSISTANCE AT 800.486.0999



#### Please take time to read and understand these installation instructions.

CORSA recommends that the installation of this system be performed by a qualified service center or professional installer who has the necessary equipment, tools and experienced personnel. However, if you decide to perform this install the use of an additional person may be required.

**CAUTION:** Never work on a hot engine bay. Allow time for the vehicle to cool.

## **Recommended Tools:**

- Flathead Screwdriver
- Assorted Socket-Set

- Ratchet
- Ratchet Extension

# Please confirm that all parts are present according to the bill of materials before beginning the installation.

If something is missing call Tech Support at 1-800-486-0999

Bill of Materials							
1	616957-O/D - CORSA CAI	1	460641 - Filter Adapter	1	534035 – 3.5" Silicone Elbow	6	59020104 – Washer Flat 0.25"
1	612009-240 - Metal Shield	3	52060 - #60 Clamp	37"	56006 – Vinyl Trim	5	59020114 – Washer Lock 0.25"
1	641052-240 - Metal Duct	1	52064 - #64 Clamp	4	59012210 – Bolt 6mm-16	1	59061210 – Nut 6mm
1	5160/5161 - Air Filter	1	53310 - 3.5" Reducer	1	59012213 – Bolt 6mm-30	1	652001 – Plastic Spacer
1	INS616957 – Instruction Sheet	1	652014 – CORSA Badge	1	652009 – Rubber Grommet	1	652002-240 – Shield Bracket



### **Installation Instructions:**

<u>Locate your vehicle's battery and disconnect the negative battery cable,</u> this resets the computer and clears old air flow data to prevent CEL errors.

- 1. Before you begin the install you must disconnect the negative battery cable. Failure to disconnect the battery may cause a check engine light or damage your engine. (Fig A)
- 2. Twist off oil cap. Pull up and out to remove engine cover. Reinstall oil cap. (Fig B)
- 3. Using a 5/16 socket or nut driver, loosen the clamp holding the air duct to the throttle body. (Fig C)
- 4. Disconnect the harness from the intake air temperature sensor. (Fig D)
- 5. Disconnect vacuum hose from air box and engine. (Fig E)
- 6. Remove air box mounting bolt from front of air box. (Fig F) Save for reinstallation.
- 7. Slide air duct off throttle body and pull intake assembly up and out to remove from vehicle. (Fig G)
- 8. Remove air temperature sensor from stock air duct. (Fig H) Save for reinstallation.

**WARNING:** Over tightening hardware may alter the integrity of the CORSA air intake system.

- 9. Install the supplied grommet along with the factory intake air temperature sensor into the CORSA air duct. (Fig I)
- 10. Bolt filter adapter to heat shield using supplied socket head bolts, lock washers, and flat washers. (Fig J)
- 11. Install vinyl trim pieces on CORSA heat shield. Where applicable, add a relief cut to allow trim to form around sharp bend. (Fig K)
- 12. Loosely assemble bracket to shield using supplied hardware. (Fig L)
- 13. Remove factory 10mm bolt from inner fender. (Fig M)
- 14. Insert CORSA heat shield into vehicle. (Fig N)
- **15.** Place supplied spacer between CORSA heat shield and inner fender and attach to vehicle using supplied hardware. Tighten.(**Fig O**)
- 16. Using factory bolt removed in step 6, attach CORSA heat shield to factory mounting point. Tighten. (Fig P)
- 17. Fully tighten hardware holding bracket to heat shield installed in step 12. (Fig Q)

CONTINUED ON NEXT PAGE

INS616957

CORSA Performance 140 Blaze Industrial Pkwv Berea. OH 44017 · P: (440) 891.0999 ·F: (440)891-1868



- 18. Install silicone hump hose onto filter adapter. (Fig R)
- 19. Install shorter end of silicone elbow onto duct. (Fig S)
- **20.** Insert CORSA intake tube into silicone hump hose and over throttle body. Adjust duct as necessary and tighten hose clamps. (Fig T)
- 21. Install filter onto filter adapter inside CORSA heat shield and tighten clamp. (Fig U)
- 22. Install supplied vacuum hose. (FIG V)
- 23. Plug in supplied air intake temperature sensor extension into vehicle harness then into temperature sensor inside duct. (FIG W)
- 24. Place CORSA Performance badge on heat shield or any other desired location.
- 25. Reattach the negative battery cable and recheck all connections before driving and retighten the clamps after 500 miles. (Fig X)

\*Check that this air intake complies with your Federal, State and Local laws. We recommend saving your stock system.

#### **BEFORE ROAD TESTING**

- 1. Start engine, leaving the transmission in park and securing the parking brake.
- 2. Make sure to look and listen for any unusual noises or air leaks. Repair problems if needed.
- 3. Once completed it will be necessary to check periodically, after a few heat cycles, for realignment and tightening of all connections.

#### **CARE AND CLEANING**

Check the reusable filter periodically and remove any excessive dirt build-up by tapping the filter on the ground and brushing off the loosened dirt.

Clean the **MaxFlow 5** (Blue) filter by using a two stage cleaning kit to thoroughly clean and re-oil the filter. Re-oil every 10,000-15,000 miles without cleaning to improve filtering in sand and dirt. Clean only when dirt is very excessive or at or before 40,000 miles.

For **DryTech 3D** (Red) filters remove excess dirt by tapping the filter on the ground. Vacuum clean for a quick clean. Rinse DryTech 3D filters with water every 50,000 miles and allow to dry completely prior to re-installation. Do Not Oil!

FOR REPLACEMENT FILTERS REFERENCE #5160/5161 & CALL 440-891-0999 OR TOLL FREE 1-800-486-0999

PICTURES ON NEXT PAGE

## **Installation Pictures**



Fig. A



Fig. B



Fig. C



Fig. D



Fig. E



Fig. F

## **CONTINUED ON NEXT PAGE**



# **Installation Pictures**



Fig. G



Fig. H



Fig. I




Fig. J



Fig. K



Fig. L





## **Installation Pictures**



Fig. M



Fig. O



Fig. Q



Fig. N



Fig. P



Fig. R

**CONTINUED ON NEXT PAGE** 



# **Installation Pictures**



Fig. S



Fig. U



Fig. W



Fig. T



Fig. V



Fig. X