

INSTALLATION INSTRUCTIONS FOR DYNOMAX VT KIT **38397**

2009-03 Dodge Ram 2500/3500 5.7L Hemi V8, 8.0L V10 - 140" & 160" wheelbases, 2/4WD

Danger Warning: Should the purchaser decide to install any exhaust product at home, be warned that passenger car or light duty truck/van bumper jacks are intended for emergency use only. The use of frame contact jack stands, in conjunction with a floor jack as main support, is highly recommended to minimize accidental dropping of a vehicle during the installation process.

Note: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe, muffler, and tail pipe from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install Dynomax front intermediate pipe **53750** for 140" wheelbase models or pipe **54734** for 160" wheelbase models. Insert the rod hanger into the rubber isolator. Slightly tighten the inlet 3" clamp.
3. Install Dynomax VT muffler **17957** with the side connection as the inlet. Slightly tighten the 3" clamp that connects the muffler to the inlet pipe.
4. Install extension pipe **51061**. The inlet end of this extension pipe may need to be shortened by cutting with a hack saw or power saw. Test fit with the tail pipe before final assembly.
5. Install Dynomax tail pipe **55560**. Insert the metal rod hangers into the rubber isolators on the chassis.
6. Install Dynomax stainless steel tip **36474** using the band clamp that is included with the tip. Position the band clamp with the fasteners on top.
7. Beginning at the inlet end, align all the parts and fully tighten all the clamps.
8. Please see the system diagram on the back page of these instructions.

Kit Contains:

- (1) 53750 intermediate pipe
- (1) 54734 intermediate pipe
- (1) 17957 VT muffler
- (1) 51061 extension pipe
- (1) 55560 tail pipe
- (1) 36474 tip w/ 3" band clamp
- (4) 3" band clamp
- (1) instruction sheet

Form: 711415
02/2011