

## INSTALLATION INSTRUCTIONS FOR DYNOMAX VT MUFFLER KIT **38454**

2008-07 Chevrolet Silverado 1500 / GMC Sierra 1500 4.8L, 5.3L V8 Crew cab, short bed & Ext cab, standard bed, 143.5" wheelbase, 2/4WD single exhaust

**Danger Warning:** Should the purchaser decide to install any exhaust product at home, be warned that passenger car or light duty truck/van bumper jacks are intended for emergency use only. The use of frame contact jack stands, in conjunction with a floor jack as main support, is highly recommended to minimize accidental dropping of a vehicle during the installation process.

**Note:** Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers from the rubber isolators.
2. Install Dynomax front intermediate pipe **55520**. Insert the metal rod hanger into the rubber isolator on the chassis. Finger tighten the nuts on the inlet flange. Slip a 3" band clamp over the outlet end of this pipe.
3. Install Dynomax VT muffler **17949** and outlet extension pipe **51075**. The muffler should lie flat and install with the center connection as the inlet and the side outlet connection toward the passenger side. The 51075 extension pipe may need to be shortened with a hack saw or power saw. Test fit with tailpipe.
4. Install Dynomax tail pipe **55516**. Insert the three (3) metal rod hangers into the rubber isolators on the chassis.
5. Beginning at the inlet end, align the exhaust system components and fully tighten the clamps.
6. Please see the system diagram on the back page of these instructions.

### Kit Contains:

- (1) 55520 inlet pipe
- (1) 17949 muffler
- (1) 51075 extension pipe
- (1) 55516 tail pipe
- (3) 3" band clamp
- (1) instruction sheet

Form: 711416  
02/2011