

## INSTALLATION INSTRUCTIONS FOR DYNOMAX VT MUFFLER KIT **38501**

2011-2009 Chevrolet Colorado / GMC Canyon 5.3L

**Danger Warning:** Should the purchaser decide to install any exhaust product at home, be warned that passenger car or light duty truck/van bumper jacks are intended for emergency use only. The use of frame contact jack stands, in conjunction with a floor jack as main support, is highly recommended to minimize accidental dropping of a vehicle during the installation process.

**Note:** Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers from the rubber isolators.
2. Install Dynomax front exhaust pipes **52475** and **53751**. Insert the metal rod hangers into the rubber isolators on the chassis. Slightly tighten the clamp and flange nuts on the exhaust pipes.
3. Install Dynomax VT muffler **17949**. The muffler should lie flat and install with the center connection as the inlet with the side outlet connection toward the drive shaft. Slightly tighten the 3" inlet clamp at the connection to the front pipe.
4. Install Dynomax tail pipe **55562**. Insert the two (2) metal rod hangers into the rubber isolators on the chassis. Slightly tighten the 3" clamp to the muffler outlet.
5. Install the **36474** tip with the supplied band clamp.
6. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
7. Please see the system diagram on the back page of these instructions.

### Kit Contains:

- (1) 52475 inlet pipe
- (1) 53751 y-pipe
- (1) 17949 muffler
- (1) 55562 tail pipe
- (1) 36474 SS tip w/ 3" band clamp
- (2) 3" band clamp
- (1) 2 1/2" band clamp
- (1) 2 3/4" band clamp
- (1) instruction sheet

Form: 711399  
02/2011