

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39397**

2009-03 Dodge Ram 2500/3500 5.7L Hemi V8 8.0L,
V10 - 140" & 160" W.B., 2 / 4 W.D.



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before beginning installation.

1. Remove the OE inlet pipe, muffler and tail pipe from the vehicle. Lubricate the rubber isolators with WD-40, or similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front intermediate pipe **53750** for 140" W.B. models or pipe **54734** for 160" W.B. models. Insert the rod hanger into the rubber isolator. Finger tighten the inlet 3" clamp.
3. Install DynoMax Ultra Flo Welded muffler **17233** with the side connection as the inlet. Finger tighten the inlet 3" clamp that connects the muffler to the inlet pipe.
4. Install DynoMax tail pipe **55560**. Insert the metal rod hangers into the rubber isolators on the chassis. Use the other 3" clamp to connect the tail pipe to the muffler outlet.

5. Install DynoMax stainless steel tip **36474** using the band clamp that is included with the tip.
6. Beginning at the inlet end, align all the parts and fully tighten all the clamps
7. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17233 MUFFLER
- (1) 53650 INTERMEDIATE PIPE
- (1) 54734 INTERMEDIATE PIPE
- (1) 55560 TAIL PIPE
- (1) 36474 TIP
- (4) 3" BAND CLAMPS
- (1) 710774 INSTRUCTION SHEET

39397 SYSTEM DIAGRAM

