

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39510**

2012 Jeep Wrangler, Wrangler Unlimited 3.6L
2011-07 Jeep Wrangler, Wrangler Unlimited 3.8L



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS OR SCISSOR JACK ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the OE muffler assembly from behind the OE intermediate pipe. Lubricate the rubber isolators with WD-40, or similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax Super Turbo SS muffler assembly **53804**. Slightly tighten the 2½" clamp that connects this muffler to the outlet of the OE intermediate pipe.
3. Install the DynoMax SS tips 36484. See the system diagram on the back page of these instructions.

4. Beginning at the inlet end, align the muffler assembly and tighten all clamps.

KIT CONTAINS:

- (1) 53804 MUFFLER ASSEMBLY
- (2) 36484 SS TIPS w/2½" CLAMPS
- (1) 36438 2½" BAND CLAMP
- (1) 711990 INSTRUCTION SHEET

39510 SYSTEM DIAGRAM

