

*Congratulations on your purchase of a quality Dee Zee product. Dee Zee is recognized as having the highest quality running boards and accessories on the market today. We have earned this reputation by offering our customers a product they can be proud to place on their vehicles. Dee Zee meets all the criteria of manufacturing a custom-fit product which guarantees it to be the easiest product to install.*

Instructions: Please take the time to read all of the installation instructions carefully before beginning this installation.

#### **TWO YEAR WARRANTY FOR CHROME STEEL AND BLACK STEEL PRODUCTS**

Dee Zee Manufacturing, Inc. guarantees the original purchaser of Dee Zee products a five year warranty against manufacturing defects in materials, workmanship, and finish under normal use. **Warranty does not include shipping damage, product misuse, improper installation, road hazards, impairments from accidents, product modifications or product neglect, and or scratches during the life of the product. This warranty does not include rust incurred / and or corrosion to the installation brackets over the life of the product.** This five year warranty applies only to new products and is limited to the repair or replacement of Dee Zee products. Warranty does not include costs of removal, installation, labor, inconvenience or consequential damages. Original purchaser must return defective merchandise, along with the purchase receipt, to the original place of purchase.

#### **FINISH PROTECTION AND CLEANING INSTRUCTIONS**

Dee Zee products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish, or wax that contains an abrasive is detrimental to the finish, as the compounds scratch the finish and open it to corrosion. The use of a black automotive type touch up paint is recommended to cover up any rock chips that would be incurred during everyday use to help in the prevention of corrosion.

#### **LIFETIME WARRANTY FOR CHROME STAINLESS STEEL PRODUCTS**

Dee Zee Manufacturing, Inc. guarantees the original purchaser of Dee Zee products a lifetime warranty against manufacturing defects, materials, workmanship, and finish under normal use. **Warranty does not include shipping damage, product misuse, improper installation, road hazards, impairments from accidents, product modifications or product neglect, and or scratches during the life of the product. This lifetime warranty does not include rust incurred / and or corrosion to the installation brackets over the life of the product.** This lifetime warranty applies only to new products and is limited to the repair or replacement of Dee Zee products. Warranty does not include costs of removal, installation, labor, inconvenience or consequential damages. Original purchaser must return defective merchandise, along with the purchase receipt, to the original place of purchase.

#### **FINISH PROTECTION AND CLEANING INSTRUCTIONS**

Dee Zee products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish, or wax that contains an abrasive is detrimental to the finish, as the compounds scratch the finish and cause corrosion.

*If you should incur any problems with the installation of this product, please call us at  
**1-800-779-8222.***

*So that we may better serve you when you call, please have the Part Number, Bar Code  
Number or Upc Code from the labels on the outside of the box.*

## Dee Zee Nerfstep Installation Instructions

DZ 370112 (Chrome) / DZ 370111 (Black)

(Chevy Tahoe / GMC Yukon 1995 – 2000 2-door) (Chevy / GMC Blazer 1992-1994 2-door)  
(Chevy Regular Cab Pickup / GMC Regular Cab Pickup 1988 – 1998)

### Parts List:

QTY:1 - Right Nerfstep  
QTY:1 - Left Nerfstep  
QTY:1 - Set of Nerfstep Mounting Brackets  
QTY:4 - 1/2" x 1 1/2" Hex Head Bolts  
QTY:8 - 1/2" Lock Washers  
QTY:4 - 1.75x120mm Hex Head Bolts  
QTY:8 - 1/2" Flat Washers

### Installation Instructions:

- 1 - Read and understand instructions completely before beginning this installation. **Note: This is a non-drill application.**
- 2 - Bolt the nerfstep mounting brackets to the nerfstep ends using 1/2" x 1 1/2" hex head bolts, 1/2" flat washers, and 1/2" lock washers as shown below. Tighten into place using a 3/4" wrench / or socket.
- 3 - Locate and remove the four body-shock mounting bolts from the vehicle using a 15mm wrench / or socket and discard.  
Note: The body mounting steel washer plates and rubber bushings are reused between the body mount and the nerfstep mounting bracket.
- 4 - The nerfstep and nerfstep mounting brackets are pre-assembled to match the vehicle body mounting locations. If any additional adjustment should be required, this can be accomplished by loosening the pre-torqued 1/2" hex head bolt that retains the mounting bracket to the nerfstep, and re-torquing to 65 ft./lbs.
- 5 - Position the nerfstep assembly under the body mounts as shown below. Install the M12-1.75 x 120mm hex head bolts, 1/2" lock washers and 1/2" flat washer up thru the hole in the nerfstep mounting bracket and the body mount steel washer plates and rubber bushing as shown. Torque the M12-1.75 x 120 mm hex bolt to 45 ft./lbs.

