



BODY MOUNT BUSHING INSTALLATION INSTRUCTIONS

Prothane Motion Control highly recommends this and all our polyurethane suspension kits be installed by a qualified automotive technician. Please refer to a factory service manual before any disassembling or reassembling of your vehicle, for proper specifications. Check service manual to make sure all torque specs are properly done.

*NOTE: PROTHANE does not provide any hardware in body mount kit 6-108. The parts numbers that are listed beside the hardware illustrations are factory part numbers to help guide you when referring to the factory manual.

NOTE: All lubricants, oils, silicone, rubber and debris must be removed from all surfaces of the body mount assys Prior to installation.

