

DiabloSport Catch Can Installation Instructions

Installation for Ram Truck 09-UP Catch Can Installation Instructions

Warning: This installation should be performed while your vehicle is off and has not been operated for at least several hours to avoid coming in contact with any hot parts.

1. Remove the factory PCV hose.
2. Locate the accessory hole on the passenger side cylinder head.
3. Remove the wiring harness clip from the factory hole if you need to (not mandatory).
4. Using the provided bolt and lock washer-install the bracket.
5. Adjust the bracket so your Catch Can fits properly.
6. Once the can is in place, attach the provided hose as shown in line with the PCV hose.



This picture is a representation of installation and may not resemble your vehicle.

Note: For the first month or two check your oil levels frequently. Take note of how fast your can fills up (this will depend on driving style.) Discard oil at a proper discard station and reattach can. Never add oil from catch can back into your engine. After your vehicle's characteristics have been established, check your catch can's oil levels regularly.

Product Liability Statement: By purchasing this product for DiabloSport the customer and DiabloSport Inc. enter into an agreement to which DiabloSport assumes no liability for damages or injury incurred by the buyer or installer of this product. The buyer has complete responsibility for installation, use, and upkeep of this catch can.