

OPEN FIRST!!



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts list for Master set # 2-18101

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start.**

Transmission mount:

Note: for CJ with V8, replaces factory part # 1370910

- 1 - 1036 mount
- 1 - 15.810 backing plate
- 2 - 15.348 (7/16" lockwasher)
- 4 - 15.342 (7/16" flat washer)
- 2 - 15.530 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions

Transmission mount:

- 2 - 4403

Front leaf spring and shackle bushing set:

- 4 - 2223 main eye bushings
- 2 - 15.008 (3/4" O.D. x 9/16" I.D. x 3.00" sleeve)
- 8 - 2086 rear spring eye and frame shackle bushings
- 4 - 15.002 (3/4" O.D. x 1/2" I.D. x 3.085" sleeve)
- 1 - 17040 installation instructions

Rear leaf spring and shackle bushing set:

- 4 - 2223 main eye bushings
- 2 - 15.008 (3/4" O.D. x 9/16" I.D. x 3.00" sleeve)
- 8 - 2086 rear spring eye and frame shackle bushings
- 4 - 15.002 (3/4" O.D. x 1/2" I.D. x 3.085" sleeve)
- use 17040 installation instructions

Body mount set:

- 1 - 4017 bushing, molded on nipple (# molded on part)
- 1 - 4019 bushing (.400" hgt. x .675" I.D.)
- 4 - 4081 bushing (.670" hgt. x 1-1/4" I.D.)
- 6 - 4074 bushing, molded in sleeve (# molded on part)
- 4 - 4075 bushing, molded in sleeve (# molded on part)
- 6 - 4080 bushing, conical shape (# molded on part)
- 10 - 15.305 (2" O.D. x 1/2" I.D. washer)
- 1 - 17033 installation instructions

Parts list continued:

Front tracking arm bushing set:

- 4 - 7036 bushings
- 2 - 15.102 (3/4" O.D. x 1/2" I.D. x 1.600 sleeve)
- 1 - 17039 installation instructions

Rear pan hard bar bushing set:

- 4 - 7036 bushings
- 2 - 15.102 (3/4" O.D. x 1/2" I.D. x 1.600 sleeve)
- use 17039 installation instructions

Complete front swaybar bushing and endlink grommet set :(15/16" and 1-1/8" diameter bar)

- 2 - 5009 (15/16" bushings)
- 2 - 5012 (1-1/8" bushings)
- 4 - 2201 upper and lower endlink grommets
- 1 - 17039 installation instructions

Tie-rod boot sets:

- 4 - 13001 tie-rod boots

Grease:

- 2 - 9.11101 grease tub

Additional parts available for your vehicle:

Shock boots

fits most aftermarket shocks (sold in pairs)
set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see catalog at your place of purchase.

17191

4/1/99 Knjl
Updated 091003 NJT