

# OPEN FIRST!!

# ENERGY SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2000 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

## Parts list for Master set # 2-18107

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start**.

#### Front control arm bushing set: 2-3106

- 4 3300 lower control arm bushings.
- 4 3301 lower control arm bushings.
- 4 15.10.237.39 (7/8"O.D. x 9/16" I.D. x 2.600" sleeve)
- 4 3354 upper control arm bushings.
- 2 3353 upper control arm bushings.
- 1 3362 upper control arm bushing.
- 1 3363 upper control arm bushing.
- 4 15.10.243.39 (3/4"O.D. x .406" I.D. x 2.038" sleeve)
- 1 17280 installation instructions

#### Rear control arm bushing set: 2-3107

- 4 3300 lower control arm bushings.
- 4 3301 lower control arm bushings.
- 4 15.10.237.39 (7/8"O.D. x 9/16" I.D. x 2.600" sleeve)
- 4 3354 upper control arm bushings.
- 4 3352 upper control arm bushings.
- 4 15.10.243.39 (3/4"O.D. x .406" I.D. x 2.038" sleeve)
- 1 17280 installation instructions.

#### Front spring isolator set: 2-6101

- 2 6112 spring isolator.

#### Front and Rear bump stop set: 2-9101

- 4 6113 bump stop (2 EA. 6113 PER. SET).

#### Front sway bar bushing set: 2-5110

- 2 5348 30mm sway bar bushings.
- 2 15.12.06.39 sway bar brackets assemblies.
- 4 8043 end link bushings.
- 4 15.10.251.39 (5/8"O.D. X 1/2" I.D. X 1.300" sleeve)
- 1 17039 installation instructions.
- 1 17145 installation instructions.

#### Rear sway bar bushing set: 2-5111

- 2 5333 16mm sway bar bushings.
- 2 15.12.06.39 sway bar brackets assemblies.
- 4 15.03.23.39 (.702"O.D. X .402" I.D. X .090" THK.)
- 4 8217 end link bushings.

#### Front track arm bushing set: 2-7102

- 2 7039 track arm bushings.
- 1 15.10.112.39 (5/8"O.D. X 7/16" I.D. X 1.600" sleeve)
- 1 13001 tie rod boot.

### Parts list continued:

#### Rear track arm bushing set: 2-7103

- 4 7087 track arm bushings.
- 2 15.10.233.39 (7/8"O.D. X .480" I.D. X 1.600" sleeve)
- 1 17073 installation instructions.

#### Body mount set: 2-4107

- 6 4183 body mount, upper (Position 2,3,4)
- 6 4184 body mount, lower (Position 2,3,4)
- 5 4185 body mount, upper (Position 1,5,6)
- 5 4186 body mount, lower (Position 1,5,6)
- 2 6182 front grill bumper.
- 6 15.03.49.39 (2 1/2" x 1/2" flat washer)
- 5 15.03.09.39 (2" x 7/16" flat washer)
- 1 17324 installation instructions.

#### Tie rod boot set: 9.13101

- 2 13001 tie rod boots.

#### Misc.:

- 1 9.11104 Grease.

## Additional parts available for

#### Transmission mount set: 2-1103

97-99 Jeep Wrangler

#### Engine mount set: 2-1104

97-99 Jeep Wrangler

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. Please ask to see our catalog at your place of purchase.

# 17337

8/DEC/00 BRH