

# OPEN FIRST!!

## Parts list for Master set # 3-18122 84-95 CORVETTE



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start.**

#### Rack and pinion bushing set: 3-10101

- 1 - 10012 bushing
- 2 - 10013 bushing
- 1 - 15.10.154.39 (.625"O.D. x .437" I.D. x 2.450" sleeve)

#### Differential carrier mount set: 3-1103

##### Must remove factory shell

- 4 - 1003 bushing
- 2 - 15.10.117.39 (.750"O.D. x .500" I.D. x 2.562" sleeve)

#### Front control arm bushing set: 3-3142

- 2 - 3133 upper control arm bushing front position
- 2 - 15.10.129.39 (1"O.D. x .790" I.D. x 1.937" sleeve)
- 4 - 3131 upper control arm bushing rear position
- 2 - 15.10.129.39 (1"O.D. x .790" I.D. x 1.937" sleeve)
- 8 - 3130 lower control arm bushing
- 4 - 15.10.126.39 (.750"O.D. x .480" I.D. x 2.125" sleeve)
- 1 - 17052 installation instructions
- 1 - 17019 installation instructions

#### Rear control arm bushing set: 3-3145

- 8 - 3120 control arm bushing upper & lower chassis end.
- 4 - 15.10.86.39 (.750"O.D. x .500" I.D. x 1.700" sleeve)
- 8 - 3121 control arm bushing upper & lower rear hub end
- 4 - 15.10.53.39 (.875"O.D. x .625" I.D. x 1.675" sleeve)
- Use 17019 installation instructions

#### Rear spring cushion set: 3-2123

- 4 - 4086
- 4 - 15.03.21.39 (1.750" O.D. X .625" I.D. washer)

#### Tie-rod dust boot set: 9-13101

- 2 - 13001 tie-rod dust boot

#### Rear toe adjustment rod dust boot set: 9-13101

- 2 - 13001 tie-rod dust boot

#### Grease:

- 2 - 9.11101 grease tub

#### Balljoint boot set: 9-13127

- 2 - 13010 upper balljoint boots
- 2 - 13014 lower balljoint boots

### Parts list continued:

**You must identify which style strut rod your car is equipped with.**

#### Rear strut rod bushing set: 3-7107

- If the strut eye's are the same size on each end, use the following parts listed below. Fit's GM P/N14048947(LH) and GM P/N14048948(RH)
- 8 - 7024 bushing (reuse cap washer on camber adjuster)
- 2 - 15.10.53.39(.875"O.D. x .625" I.D. x 1.675" sleeve)(hub)
- 2 - 15.10.116.39(7/8"O.D. x 3/4" I.D. x 1.675" sleeve)(inner)
- 1 - 17047 installation instructions
- 1 - 17039 installation instructions

#### Or rear strut rod bushing set: 3-7108

- If the strut eye's are different on each end, use the following parts listed below. Fit's GM P/N10098131(LH) and GM P/N10098132(RH)
- 4 - 7024 bushing (hub end)
- 2 - 15.10.53.39(.875"O.D. x .625" I.D. x 1.675" sleeve)(hub)
- 4 - 7045 bushing (differential end)reuse inner metal sleeve
- Use 17039 installation instructions

## Additional parts available for your vehicle:

### Front swaybar bushing and endlink set:

	Bar dia.	set #
1988-95 Corvette	22mm	3-5140
	24mm	3-5141
	26mm	3-5154
	30mm	3-5142
1984-87 Corvette	22mm	3-5137
	24mm	3-5138
	26mm	3-5139
	30mm	3-5155

### Rear swaybar bushing and endlink set:

	Bar dia.	set #
1984-95 Corvette	19mm	3-5149
	22mm	3-5150
	24mm	3-5151
	26mm	3-5152

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see catalog at your place of purchase.